

NOTES:

- 1. SOIL CELL LAYOUT IS FOR REFERENCE ONLY
- 2. PVC TO BE PLACED MINIMUM 6" DEPTH FROM GRADE
- 3. PUT NETAFIM TUBING THROUGH SLEEVE. CONNECT TO IRRIGATION PVC HEADER IN TREE WELL
- 4. NETAFIM TUBING TO BE SECURED WITH 6" LANDSCAPE STAPLES NO LESS THAN EVERY 4 FEET AND SECURED AT ANY JUNCTION, NON-PVC HEADER, OR CONNECTION

О

SHEET

SOIL CELLS WITH IRRIGATION PLAN VIEW