


NOTES:

1. INSTALL ROOT GUARD PER MANUFACTURER'S RECOMMENDATIONS ADJACENT TO WALK OR CURB.
2. CONDUCT TREE WELL DRAINAGE TEST, IN PRESENCE OF CONSTRUCTION PROJECT REPRESENTATIVE. IF WELL DOES NOT DRAIN WITHIN 24 HOURS, A DEEPENED DRAINAGE CHIMNEY WILL BE REQUIRED. DEEPENED DRAINAGE CHIMNEY TO BE 12" DIAMETER, 8'-0" DEEP OR UNTIL CHIMNEY PENETRATES COMPACTED SOIL. FILL WITH 3/4" DIAMETER, CLEAN, WASHED GRAVEL. BOTTOM OF PIT SHALL DRAIN TOWARDS HOLE.
3. ADD PRE-EMERGENT HERBICIDE ABOVE AND BELOW MULCH

	DEPARTMENT OF PUBLIC WORKS		PROWAG AND DOWNTOWN PROJECTS	
	SURVEY & RIGHT-OF-WAY		TREE PLANTING IN TREE GRATE WELL	
DATE: 1/30/24		DRAWN BY: CP		
SHEET: 1		OF 1		
FILE NAME:				